



Conspicuity Inc.
400 Travis Lane #30
Waukesha, WI 53189
(877) 411-8551
info@conspicuityinc.com
www.conspicuityinc.com

DOING BUSINESS
WITH BIKERS FOR 28
YEARS!

USE AND CARE OF SEW-ON RETROREFLECTIVE MATERIALS

Sewing

Sew along the margins of the material, taking care not to puncture the envelope. Fold cut ends under and sew. Apply material so that it lies flat and will not be bent. Place on back or front of torso, horizontally or vertically, or around arm or leg. Do not place stripes vertically down the arm or leg; flexion or excess stretching may destroy the integrity of the reflective material.

Cleaning

Road film and bugs may be removed by placing on a flat surface, washing with a soft cloth or sponge and a mild detergent solution, and rinsing with water. Do not dry clean or place in washing machine.

Storing

Store garments on hangers, separating the fluorescent and non-fluorescent colors. If it is necessary to fold the material (though folding is not the recommended storage method), separate the folded surfaces with plain paper or cloth, *to prevent fluorescent tapes from bleeding onto other tapes when in extended close contact*. Store unused product separating the different colors with paper or cloth. Avoid extreme heat.